

## Knife Angle Setting Tool


### Pictures

#### W32 "Black Edition"



Self-centered wheel size and angle scale.


Ruler house to always stay in right position on the wheel.



Dps Angle scale divided into 0,5 Degree and wheel diameter scale



Copy the projection  
length to the ruler.

T-cube against the  
knife edge.



Adapted to fit kj-45

T-cube and ruler can be lock on to the usb support as an extra help to hold it in place.



Lock plate secure on the support shaft

Lock plate not in use

